

Installing Richmond Brothers Equipment Shovels

Before installing Richmond Brothers Equipment bolt-on shovels, clean shank free of dirt and rust.

Use 7/16 bolts Grade 5 or higher.

Use nylock or stover style lock nuts.

For 7" and 9" shovels, ensure that the mounting pads are the ONLY contact point between shank and shovel.

Torque spec is 42ft lbs. Re-torque nuts after approximately 200-300 acres.

For the best results and performance of our products, ensure that tool is level front to back.

Handle shovels with care!

Do not throw, drop, or strike shovels with an object. Do not use 1/2" impact driver or larger power tools to install.

Do not let the entire weight of the cultivator rest on shovels while on a hard surface (concrete, frozen ground, etc.).

For further information on installation, handling, and replacements, don't hesitate to contact your local dealer or Richmond Brothers Equipment at 989.453.7097.